

Easy to Use Planting System

CRESCENT
garden




Water level indicator with red line to indicate when full

Water fill hole

Volcanic rock layered at the bottom for better drainage

Rope wicks transfer water from tank to root system

Separate wheel housing



Fix the tyres in their corresponding spaces in the base section.

- Includes:**
- 1 Water level indicator with red line
 - 1 Platform with rope wicks
 - 4 Wheels (Optional)
 - 1 Drainage bag



Planting instructions

A drainage bag comes included with each Hydro-garden; its contents are sufficient to complete the following steps. Spread the drainage material uniformly on top of the conductors until they are covered by a layer approximately 2 centimeters.



Cover the drainage layer with soil, leaving a hole for each plant that you wish to plant in your Hydro-garden.



Before planting each plant in its corresponding hole we recommend that you loosen the roots (without breaking them), which will encourage the plants to take root in their new soil. If you intend to plant more than one plant, we suggest that you start with the biggest.



After planting the **FIRST** time, it is important to water the soil, slowly and at intervals until the soil and drainage layer is moist and the water tank is full. The level shown on the indicator rod will rise until the colour red starts to appear. Do not let the level rise beyond this point as it will be detrimental both for your plants and for the correct functioning of your Hydro-garden.



It is normal for the soil level to descend following the first time you water your Hydro-garden. We recommend that you use new soil to refill the garden up to its pre-watering level.

BASIC ROUND	Water tank capacity	Substrate cultivation capacity
BASIC Ø 35x35	3 Liters	18 Liters
BASIC Ø 42x40	5 Liters	38 Liters
BASIC Ø 50x40	8 Liters	49 Liters
BASIC Ø 60x50	11 Liters	73 Liters
BASIC SQUARE		
35x35x35	4 Liters	24 Liters
50x50x40	12 Liters	62 Liters
75x75x40	32 Liters	151 Liters
BASIC RECTANGLE		
75x35x40	13 Liters	65 Liters
110x40x40	25 Liters	114 Liters

Maintenance instructions.

Fill the tank 4 times a year and surface water every 4 to 5 weeks. **If using outdoors**, where planters will receive rain water, please ensure that an overflow drain is installed. If you wish, you can take the opportunity to add liquid fertilizer directly to the water tank before you refill it.

If after a few days the water level has descended or the indicator rod is at its minimum level, this does NOT mean that you should either partly or completely refill the water tank again. The water has been absorbed by the system and the soil.

You must **ONLY REFILL THE WATER TANK 4 TIMES A YEAR**. If you have planted plants with shallow roots, it is a good idea to lightly water the surface of the soil, preferably with a watering can.



Once a month, water lightly



Four times a year, refill water tank